

API OUTDOORS

Extreme Power Gripping Chains are compatible with all API treestands with a 300lb. weight capacity or below. Model #'s GS700,GS2400,GS2500,GS2500M,GS2600SS,GS2700,GS3100, GS3400, 2005GSC, 2400GSEB,2500GSE,2750GSS and 3400GSSE.

Magnum Extreme Power Gripping Chains are compatible with all API treestands with a 350 lb. weight capacity. Model #'s GS3500SMS, 3000GSEB, and 3500GSME.

After putting on a safety glass and other essential safety instruments, begin by placing your seat platform on a sturdy surface with the inserts facing towards you (illustration A). Wedge a flat head screwdriver under the outer lip of the old style insert in the treestand arm tubing (illustration B). Using the hammer, lightly tap the screwdriver until the old style insert begins to dislodge. Continue tapping until you can remove the insert from the arm tubing. Repeat steps for remaining inserts.

NOTE If the entire outer lip is broken off the old style insert and you can't wedge the screwdriver under it to remove, gently try to pull the insert out with a pair of needle nosed pliers. If you are unable to pull the insert out, or if the insert is breaking apart in the tubing, please call API Customer Service at the number below for assistance. **DO NOT TRY TO PUSH THE INSERTS FURTHER DOWN INTO THE TUBING.**

****NOTE**** The new style inserts may not be the same length as your existing inserts. This is not due to a defect with the insert. If your treestand was manufactured prior to 2003, the holes in the inserts will not line up with the holes in the tubing for your quik-pins. In this case, the quik-pin will not pass thru the insert. The quik-pin will only pass thru the treestand chain and tubing. This will not affect the integrity of the stand in any way.

After removing all of the old style inserts you can install the new style inserts by lightly tapping the inserts into the tubing with a hammer. Be sure that the notches and holes on the new inserts are facing side to side (east and west) when in the tubing (illustration C). The chain will not fit into the inserts if the holes and notches are facing up and down (north and south). Inserts are intended only to prolong the coating on the chain. It is perfectly safe to climb in your stand without having inserts in the tubing, but it will cause the chain coating to wear more quickly.

****DO NOT INSERT QUICK-PINS THROUGH LAST LINK IN CHAIN****

****DO NOT TAKE OUT QUICK-PINS TO ADJUST THE LENGTH OF CHAIN WHILE CLIMBING ONTO THE TREE.**

If you have any questions or problems, please

CONTACT US:

API Outdoors Customer Service
602 Kimbrough Drive
Tallulah, LA 71282
1-800-228-4846
customerservice@apioutdoors.com
or visit us at
www.apioutdoors.com



Illustration A



Illustration C



Illustration B